

Towel Ring / Garment Hook Installation Instructions Model No. 22-09, 22-12

NEWPORT BRASS.
The Luxury of Style

Recommended Installation by a Professional Contractor

1. Drill holes in wall at points marked using the appropriate drill size:

- Wood Screw (#10 x 1 3/4") - use: 1/8" Drill
- Toggle Screw (6-32 x 3") - use: 3/8" Drill

2. Loosen SETSCREW (4) in FLANGES (1) and remove POSTS (3). Fasten FLANGES (1) to wall using either WOOD/TOGGLE SCREWS (2). (See Fig. 1)
Align the FLANGE (1) so that upper flat is level.

3. Thread POST (3) onto FLANGE (1). Position POST (3) height to 2 3/16" from mounting surface. Secure POSTS (3) into place by tightening SETSCREWS (4). (See Fig. 2)

4. Place ESCUTCHEON (5) over FLANGE POST (3). (See Fig. 3)

5a. Towel Ring: Slide END POST (6) onto FLANGE POST (3) and secure into place with SETSCREW (4). (See Fig. 3)

5b. Garment Hook: Slide END POST (6) onto FLANGE POST (3) and secure into place with SETSCREW (4). (See Fig. 4)

